



- NOTES:
1. FUEL FILL AND VENT HOSE ARE ROUTED THROUGH CONDUIT AND UP HULL SIDE INSIDE AIR DUCT.
  2. FIT HOSE TIGHT AFTER FRAMES AND GIMBALS ARE IN PLACE, BUT BEFORE FITTING DECK SQUARE TUBE OR RUBBER FLANGES.

REMOVE PLATE AND ONE 1/2" DIA. STUD BOLT AND REPLACE WITH 1/2" DIA. PLATE OF STEEL OR 2.0" ALUM.

IF SCREW OF HULL AND ONE 1/2" DIA. STUD BOLT IS MISSING, REPLACE WITH 1/2" DIA. STUD BOLT.

THIS PLAN, INCLUDING DIMENSIONS, AND/OR SPECIFICATIONS, ARE THE PROPERTY OF SPECIALTY MARINE. ALL REVISIONS SHALL BE THE PROPERTY OF THE ISSUING OFFICE. NO PART OF THIS PLAN SHALL BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, WITHOUT THE WRITTEN PERMISSION OF SPECIALTY MARINE. THE ISSUING OFFICE IS NOT RESPONSIBLE FOR ANY DAMAGE OR LOSS OF PROPERTY OR PERSONS CAUSED BY THE USE OF THIS PLAN.

	<b>SPECIALTY MARINE</b> <small>274 Hwy 1501, Seaside, MD, 21150</small>		
	<b>26 X 9.5' LANDING CRAFT</b> <b>INBOARD PROFILE AND PLAN</b>		
	<small>SIZE: PLAN NO.</small> <b>949</b>	<small>DATE: 10/3/04</small> <b>10/3/04</b>	